



front lamp

working lamp



rear lamp

function:  
1.brake  
2.back up  
3.steering



back flip engine  
cover



FOPS&ROPS



ROPS FALLING  
DOWN





dashboard

1. left&right steering signal lamp
- 2 running hour meter
- 3.hydraulic oil temprature meter
- 4.radiator water temprature meter
- 5.ammeter
- 6.dashboard working signal lamp



XINCHAI 485